

CARBON-OFF! 2.0

METHYLENE CHLORIDE FREE CARBON REMOVER

DESCRIPTION

CARBON-OFF! 2.0 is a methylene chloride free, powerful gel that dissolves carbon buildup from all metal surfaces. **CARBON-OFF! 2.0** works quickly and easily saving time and labor.

APPLICATIONS

Excellent for use on metal surfaces, brass, popcorn kettles, deep fryers, stainless steel, nickel steel, roasting & sheet pans, pots & pans, stove parts, barbecue grills, waffle bakers, broilers & rotisseries and chinese woks.

FEATURES & BENEFITS

- Will Not Harm Any Metal Surface
- No Scrubbing - Just Spray On & Rinse Off
- Removes Baked On Carbon!
- Renews Pots & Pans

SPECIFICATIONS

FORM: Solvent-Based Aerosol
BOILING POINT: N/A
DETERGENCY: Strong
% VOLATILE BY VOLUME: 81.5%
STORAGE STABILITY: 1 year +

FLASH POINT: N/A
COLOR: Clear Blue-Green
SPECIFIC GRAVITY: 0.95-0.98
PHOSPHATES: N/A
% VOC'S: 5%

ODOR: Acetone
SOLUBILITY IN WATER: 100%
TOXICITY: 1000 ppm
BIODEGRADABLE: No
COLD STABILITY: 0°F

FORM: Solvent-Based Liquid
BOILING POINT: N/A
DETERGENCY: Strong
% VOLATILE BY VOLUME: 85.1%
STORAGE STABILITY: 1 year +

FLASH POINT: N/A
COLOR: Clear Blue-Green
SPECIFIC GRAVITY: 0.95-0.98
PHOSPHATES: N/A
% VOC'S: 49.5%

ODOR: Acetone
SOLUBILITY IN WATER: 100%
TOXICITY: 1000 ppm
BIODEGRADABLE: No
COLD STABILITY: 0°F

LABEL INFORMATION

CARBON-OFF! 2.0 METHYLENE CHLORIDE FREE CARBON REMOVER

CARBON-OFF! 2.0 is a powerful gel that dissolves carbon buildup from metal surfaces. Works quickly and easily saving time and labor.

—AEROSOL—

DIRECTIONS: SHAKE WELL BEFORE USING. Wear rubber gloves and protective eye gear. Be sure appliance is cool and dry. Spray generously, holding can 8 to 10 inches from surface. Leave on appliance for 15 minutes or as long as 5 hours, depending on the thickness of carbon buildup. Leave overnight if convenient. **CARBON-OFF! 2.0** will not harm any metal surface no matter how long it is left on. Test with small wooden stick to see if carbon is completely loose. **DO NOT SCRUB!** When carbon is completely loose, wash under cold water tap using a bristle brush or ScotchBrite pad. May also be used to clean the inside of appliances. Before using appliance be sure to wash thoroughly with warm water and soap, THEN RINSE THOROUGHLY WITH POTABLE WATER. *Do not get on skin, paint, floors, walls or plastic tile. If contact is made, wash off immediately with cold water. Do not use on (or place appliance to be cleaned on) painted surfaces, plastics, acrylics, Corian sinks and counter tops, Anolon surfaces, Calphalon or Teflon non-stick pans. THIS PRODUCT IS NOT INTENDED FOR GENERAL PURPOSE CLEANING & DEGREASING.*

DANGER: Extremely flammable. Contents under pressure. Do not expose to heat, sparks or open flame. Do not puncture or incinerate container. Avoid contact with eyes or skin. Do not store at temperatures above 120°F. Keep out of reach of children. **DO NOT FREEZE.** Use on cold surfaces only.

FIRST AID: INHALATION: Remove victim to fresh air. Seek medical attention immediately. **IF SWALLOWED:** Call a doctor, hospital emergency room or Poison Control Center. Do not induce vomiting. **EYES:** Flush with large amounts of cool running water for at least 15 minutes while holding upper and lower lids open. If irritation persists, call a physician immediately. **SKIN:** Wash repeatedly with soap and water. If irritation persists, call a physician.

CONTAINS (CAS#): Dioxolane (646-06-0), Acetone (67-64-1), Dimethyl Carbonate (616-38-6), Monoethanolamine (141-43-5), Propane/n-Butane (68476-86-8).

—LIQUID—

DIRECTIONS: Wear rubber gloves and protective eye gear. Be sure appliance is cool and dry. Brush generous coating on appliance with a bristle or pastry brush. Leave on appliance for 15 minutes or as long as 5 hours, depending on the thickness of carbon buildup. Leave overnight if convenient. **CARBON-OFF! 2.0** will not harm any metal surface no matter how long it is left on. Test with small wooden stick to see if carbon is completely loose. **DO NOT SCRUB!** When carbon is completely loose, wash under cold water tap using a bristle brush or ScotchBrite pad. May also be used to clean the inside of appliances. Before using appliance be sure to wash thoroughly with warm water and soap, THEN RINSE THOROUGHLY WITH POTABLE WATER. Do not spill or splatter. *Do Not Use On (or place appliance to be cleaned on) Painted Surfaces, Plastics, Acrylics, Corian Sinks and Counter Tops, Anolon Surfaces, Calphalon or Teflon Non-Stick Pans. THIS PRODUCT IS NOT INTENDED FOR GENERAL PURPOSE CLEANING & DEGREASING.*

DANGER: Extremely flammable. May be harmful if swallowed. Use only in a well-ventilated area. Avoid contact with eyes or skin. Do not store at temperatures above 120°F.

CONTAINS (CAS#): Dioxolane (646-06-0), Acetone (67-64-1), Dimethyl Carbonate (616-38-6), Monoethanolamine (141-43-5), Benzyl Alcohol (100-51-6).

KEEP OUT OF REACH OF CHILDREN. DO NOT FREEZE. DO NOT STORE NEAR HEAT.

HMIS RATINGS: Aerosol: Health - 2, Flammability - 3, Reactivity - 0, Personal - B. **Liquid:** Health - 2, Flammability - 1, Reactivity - 0, Personal - B.

PACKAGING INFORMATION

Available in 6x1 20 oz. cans, net wt. 16 oz., 6x1 quarts and 1/1 gallons.